

## Rotor Nozzle Installation Procedure



1. Insert the plastic end of the Hunter adjustment wrench into the lifting socket of the rotor and turn 90 degrees. Pulling up the riser will allow access to the nozzle port for



2. Visually check to make sure the nozzle screw is not blocking the socket where you are about to install the nozzle. Slip the nozzle into the nozzle socket, the nozzle socket is angled up 25 degrees.



3. The triangle on the rubber cover will always indicate the location of the nozzle and direction of the water's flow, when the rotor is retracted. After the nozzle is installed, turn the adjustment screw a quarter turn clockwise to hold the nozzle into place. Any more than a quarter rotation of the radius reduction screw will result in a minimized radius.



**4. If you can't find the answers, please contact us at your convenience.**

Viet Garden Technical Support experts are available to answer your question(s) about Hunter products and their usage. Simply call us or submit an email request.

---

**Viet Garden is Hunter Exclusive Distributor in Vietnam**

205 Dao Duy Tu St, Dist. 10, HCM City, Vietnam

Tel: 84-8-3957 4060, Fax: 84-8-3957 4059, Email: [info@vietgardens.vn](mailto:info@vietgardens.vn), Website: [www.vietgardens.vn](http://www.vietgardens.vn)