

- Stops all irrigation; enables and disables Rain Shutdown.
- 2 Sets run times and order for stations and Blocks.
- Accesses multiple options and controller settings. Different sets of options appear, depending on mode controller is in (with other keys).
- 4 Saves field inputs and edits.
- 5 Selects between fixed choices in the display, and selects Rain Shutdown yes/no when Off is pressed.
- 6 Alphanumeric buttons for data entry.
- 7 Clears display error messages; erases Program Name in Edit mode.
- 8 Determines type of schedule and actual water days On/Off for the selected Program
- 9 Navigate backward/forward through
 - displays, Programs, and Option choices, or move active station down or up (Manual mode).
- 10 Defines Start Time for automatic Programs; launches Preset programs immediately.
- Starts one or more stations immediately.
- Cycles through available Preset names, allows access for creation or editing, or immediate start with Start button.
- 3 Cycles through available Program names, allows access for creation or editing, or immediate start with Start button.
- 4 Escapes current function and exits to next highest level.

Create a Program:

Program Select to choose.

Options to name the Program.

Exit to return to Programming.

Schedule to choose and set water days.

Start, Enter to set start time.

Stations to enter stations and run times.

Stop or Pause Irrigation

OFF to cancel all (Enter or Toggle to select Rain Shutdown or just stop current irrigation)

OPTIONS, ENTER to Pause (**OPTIONS, ENTER** to Resume)

Start a Station

Manual, type station, Enter, type runtime.

Enter to select more stations.

Enter to choose Pump & Seq./Sim. operation

Enter to start; Back or Next to start next station down or up.

Program Stations:

Stations: Press once to show total, again to show individual stations in a Program.

Choose Event #, then choose Sta # or Block #, then type run time and Enter.

Stations again, to program next Event.

Exit to save changes and leave programming.

Options

Pause Watering List FC Settings Edit FC Settings **Block Programming** Remove Program Remove Preset

Edit Decoders (if applicable)

View SYS Events **Del SYS Events**

only)

Radio Xmit Test (radio FCs

Controller Options (Edit FC Settings)

Address Time Date

PINs

Main % Scale Schedule Length Schedule Day Day Change FCP Inhibit? Response MR Runtime MR Pump

Program Options

Edit Program name Set Program % scale Cycles Cycle Delay Skip Days Pump

Cluster Events Move Event Insert Event Day and Time

Station Options

0:47

Time Remaining on

current station

Delete Event

A01.001 **Display Codes:** A=Automatic

S=Semi-automatic Sim=Simultaneous Manual Seg=Seguential Manual P=Preset

SYS=System Program Event SME=System Manual Event

#562190 Rev 12/01

